

Parts List - 498-ENTW Morgan Creek

Item Number	Item Description	Part Description	
498-EC69	Entertainment Hutch	498-EC69-1 Light Kit 498-EC69-10 Left Side Frame 498-EC69-11 Right Side Frame 498-EC69-12 Adjustable Shelf 498-EC69-13 Bottom Rail Back 498-EC69-14 Rail Back Panel 498-EC69-2 Top Shelf 498-EC69-4 Assembly Hardware 498-EC69-5 Shelf clips	

Item Number	Item Description	Part Description	
498-EL00B	Left Pier Base	498-EL00B-2 Knob Hardware 498-EL00B-3 Dower Glides 498-EL00B-4 Shelf 498-EL00B-7 Shelf Clips	

Item Number	Item Description	Part Description	
498-EL00T	Left Pier Top	498-EL00T-1 Light Kit 498-EL00T-10 Metal Connecting Plate 498-EL00T-3 Bottom Door Roller 498-EL00T-4 Back panel 498-EL00T-5 Shelf Clips 498-EL00T-7 Assembly Hardware 498-EL00T-9 Wood Shelf	

Item Number	Item Description	Part Description	
498-ER00B	Right Pier Base	498-ER00B-2 Knob Hardware 498-ER00B-3 Drawer Glides 498-ER00B-4 Shelf 498-ER00B-7 Shelf Clips	

Item Number	Item Description	Part Description	
498-ER00T	Right Pier Top	498-ER00T-1 Light Kit 498-ER00T-3 Bottom Door Roller 498-ER00T-5 Shelf Clips 498-ER00T-6 Wood Shelf	

Item Number	Item Description	Part Description	
498-TV68	Entertainment TV Stand	498-TV68-10 Shelf Side 498-TV68-14 Middle Shelf 498-TV68-17 Assembly Hardware 498-TV68-18 Top Left Moulding 498-TV68-19 Top Right Moulding 498-TV68-20 Bottom Left Moulding 498-TV68-21 Bottom Right Moulding 498-TV68-22 Door Catch 498-TV68-6 Knob Hardware 498-TV68-7 Hinges 498-TV68-8 Drawer Glides 498-TV68-9 Shelf Clips 498-TV68-P Finish Wood Panel-White 498-TV68-Q Finish Wood Panel - Tobacco	